


W/D/V-A1 Parts List



Ref No.	Part No.	Description	Qty.
1	26230A000	Ring Handle	1
2	14077-000-1	Pipe Plug	1
3	*	Motor Housing	1
4	*	Stator/Seal Plate/Rotor and Shaft Assembly	1
5	139-014-1	Seal Ring	1
6	14770-005-1	Pan Screw 5	6
7	8521-101-1	Bottom Plate	1
8	14770-002-1	Pan Screw 6	5
9	8520-002-1	Base	1
10	8498-003-1	Impeller	1
11	21607A001	Shaft Seal	1
12	14770-001-1	Screw	1

Ref No.	Part No.	Description	Qty.
13	6000-053-1	Wire with Terminal	1
14	834-030-1	O-Ring	1
15	75-005-1	Cord Nut	1
16	14623-010-1	Power Cord 10'	1
16	14623-020-1	Power Cord 20'	1
FOR AUTOMATIC OPERATION			
NOT SHOWN	12150-110-5	Wide Angle Switch 10'	1
NOT SHOWN	12150-120-5	Wide Angle Switch 20'	1
NOT SHOWN	14974-000-5	Diaphragm Switch 10'	1
NOT SHOWN	14974-001-5	Diaphragm Switch 20'	1
NOT SHOWN	13869-510-5	Vertical Switch 10'	1
NOT SHOWN	13869-520-5	Vertical Switch 20'	1

*Replace pump